

### PRODUCT DESCRIPTION

Stonchem 577 is a 100% solids, high performance, epoxy hybrid lining system applied at a nominal thickness of 3 mm. The mortar, engineering fabric, mineral composite topcoat sequencing provides a chemical barrier for resistance to occasional rubber wheels and foot traffic, thermal shock, thermal cycling, static cracks and permeation. The Stonchem 577 system has excellent resistance to caustics and moderate concentrations of acids.

### USES, APPLICATIONS

- Secondary containment areas
- Tank farms
- Sumps and trenches
- Pump pads and pedestals
- Neutralization pits
- Process floors

### PRODUCT ADVANTAGES

- Excellent chemical resistance to caustics and moderate concentrations of acids
- Engineering fabric resists cracking
- Mineral composite topcoat for increased impermeability
- Factory proportioned units for easy handling

### CHEMICAL RESISTANCE

Stonchem 577 is formulated to resist a variety of chemical solutions. (Refer to the Stonchem 500 Series Chemical Resistance Guide, which lists reagent concentration and temperature recommendations for each product.)

### PACKAGING

Stonchem 577 is packaged in units for easy handling. Each unit consists of:

#### Base

1 carton of Stonchem 500 Series Mortar  
 A carton contains:  
 6 foil bags of amine  
 6 poly bags of resin  
 6 bags of Mortar aggregate

#### Engineering Fabric

1 roll of Engineering Fabric 18.58 m<sup>2</sup> roll

### PHYSICAL CHARACTERISTICS

Compressive Strength (ASTM C-579)	69 N/mm <sup>2</sup>
Tensile Strength (ASTM D-638)	28 N/mm <sup>2</sup>
Flexural Strength (ASTM C-580)	47 N/mm <sup>2</sup>
Flexural Modulus of Elasticity (ASTM C-580)	1.1 x 10 <sup>4</sup> N/mm <sup>2</sup>
Hardness (ASTM D-2240, Shore D)	85 to 90
Abrasion Resistance (ASTM D-4060, CS-17)	0.012 gm max. weight loss
Thermal Coefficient of Linear Expansion (ASTM C-531)	2.2 x 10 <sup>-5</sup> m/mm°C
Color	Gray

**Note:** The above physical properties were measured in accordance with the referenced standards. Samples of the actual system, including binder and filler, were used as test specimens.

### Saturant

0.4 cartons of Stonchem 500 Series Saturant  
 A carton contains:  
 6 foil bags of amine  
 6 poly bags of resin

### Topcoat

1 carton of Stonchem 500 Series Topcoat  
 A carton contains:  
 4 foil bags of amine  
 4 poly bags of resin

### COVERAGE

Each unit of Stonchem 577 will cover approximately 16.72 m<sup>2</sup> at a thickness of 3 mm.

**Note:** Coverage rates shown are theoretical. Actual coverage rates may vary. Make necessary allowances for the condition of the surface to be coated, working conditions, waste, spillage, experience level and skill of the installers, etc.

## STORAGE CONDITIONS

Store all components between 10 to 24°C in a dry area. Keep out of direct sunlight. When stored in the unopened containers at the proper temperatures, the shelf life is 3 years. Store all engineering fabric in a clean and dry area.

## SUBSTRATE PREPARATION

Proper preparation is critical to ensure an adequate bond. The substrate must be dry and free of all wax, grease, oils, fats, soil, loose or foreign materials and laitance. Laitance and unbonded cement particles must be removed by mechanical methods, i.e., abrasive blasting or scarifying. Other contaminants may be removed by scrubbing with a heavy-duty industrial detergent and rinsing with clean water. The surface must show open pores throughout and have a sandpaper texture. For recommendations or additional information regarding substrate preparation, contact Stonhard's Technical Service Department.

## APPLICATION GUIDELINES

Before mixing and applying any material, make sure environmental conditions are satisfactory for application. For optimal working conditions, substrate temperature must be between 15 to 27°C. Measure the surface temperature with a surface thermometer. Cold areas must be heated until the slab temperature is above 13°C. This will allow the material to achieve a proper cure. Also, a cold substrate will make the material stiff and difficult to apply. Warm areas or areas in direct sunlight must be shaded or arrangements made to work during evenings or at night. A warm substrate (15 to 27°C) will aid in the material's workability; however, a hot substrate (27 to 37°C) or a substrate directly in the sun will shorten the material's working time and can cause other phenomenon such as pinholing and bubbling.

## APPLYING

### Priming

Vacuum the surface before priming and make sure the substrate is dry. The use of HT Primer is necessary in all applications of Stonchem 577. This ensures maximum product performance. (See the HT Primer product data sheet for details.)

**Note:** The HT Primer must remain tacky during installation of the Mortar.

### Mortar

Mix amine and resin in a 5 gallon mixing bucket on a J.B. Blender for one minute. Next, gradually add the Mortarcoat aggregate while mixing for an additional 90 seconds. Mixing is complete when no clumps of dry material exist. For vertical applications use Vertical Mortar aggregate. Apply the mortar onto the substrate with a 3/8 in. x 3/8 in. V-notched trowel. To obtain the proper thickness, hold the trowel at approximately 45 degrees and keep the tips of the V-notches in contact with the substrate. The material must be applied evenly over the substrate with no clumps or ridges present before embedding the engineering fabric.

The engineering fabric will not remove or hide any unevenness in the troweled mortar layer. If applying mortar on a vertical surface, use the same V-notched trowel to spread the material, then finish smooth with a flat steel finishing trowel. A smooth and even distribution of the material must exist on a vertical surface before embedding the reinforcement.

### Engineering Fabric

Place the engineering fabric on the mortar immediately after the mortar is applied. Press the fabric onto the mortar using a dry, medium nap roller. Overlap adjacent fabric 13mm. Immediately apply the saturant.

### Saturant

Mix amine and resin in a 5 gallon mixing container using a heavy-duty, slow-speed drill (400 to 600 rpm) with a Jiffy Mixer for one minute. Apply the saturant to the engineering fabric with a saturated medium nap roller. To wet the roller, dip it into the mixing bucket. Always work from the bucket. Do not pour the saturant directly onto the glass because this will decrease the saturant's coverage. If the air temperature is high, use of plastic mixing buckets will increase the pot life of the material. The fabric is completely saturated when white strands are no longer present. When the fabric is completely saturated, roll with a ribbed roller to release air pockets in the reinforcement and to embed the fabric into the mortar. To saturate the overlaps, roll several times over the length of the overlap with a saturated roller, then roll with a ribbed roller several times until overlap is no longer visible. Allow the mortar, fabric and saturant to cure (usually 4 to 6 hours) before proceeding.

### Topcoat

Lightly sand the saturant and fiberglass in areas where protrusions exist. Vacuum the area completely. Mix the amine and resin in a 5 gallon mixing container using a heavy-duty, slow-speed drill (400 to 600 rpm) with a Jiffy Mixer for 2 minutes. Pour the material onto the floor and spread out with a 15 mil notched squeegee. Backroll the area with a medium nap roller to remove squeegee lines, using long roll strokes to decrease the visibility of roller lines. For vertical surfaces, pour a bead of material along the base of the wall and, using a medium nap roller, roll the material onto the vertical surface. The wet film thickness of the coating is 250 to 300 microns. Check the thickness with a wet film gauge.

## CURING

The surface of Stonchem 577 will be tack-free in 4 to 6 hours at 21°C. The coated area may be put back in service in 24 hours at 21°C. Ultimate physical characteristics will be achieved in 7 days.

## RECOMMENDATIONS

- Apply only on clean, sound, dry and properly prepared substrates.
- Minimum ambient and surface temperature is 13°C at the time of application.
- Maximum surface temperature should not exceed 32°C during application. Substrate temperatures above 38°C will drastically affect the working time of the product.
- Substrate temperature should be greater than 3°C above dew point.
- Material should not be applied if humidity is above 85%.
- Application and curing times are dependent upon ambient and surface conditions. Consult Stonhard's Technical Service Department if conditions are not within recommended guidelines.

## PRECAUTIONS

- Toluene or Xylene solvents are recommended for clean up of Stonchem 577 material spills. Use these materials only in strict accordance with the manufacturer's recommended safety procedures. Dispose of waste materials in accordance with government regulations.
- The use of NIOSH/MSHA approved respirators using an organic vapor/acid gas cartridge is recommended.
- The use of protective clothing such as long sleeve shirts, safety goggles and impermeable gloves is highly recommended.
- In case of contact, flush the area with copious amounts of water for 15 minutes and seek medical attention. Wash skin with soap and water.
- Use only with adequate ventilation.

## NOTES

- Material Safety Data Sheets for Stonchem 577 are available upon request.
- Specific information regarding chemical resistance of Stonhard 577 is available in the Stonchem 500 Series Chemical Resistance Guide.
- A staff of technical service engineers is available to assist with product application, or to answer questions related to Stonhard products.
- Requests for technical literature or service can be made through local sales representatives and offices, or corporate offices located worldwide.

## IMPORTANT:

Stonhard believes the information contained here to be true and accurate as of the date of publication. Stonhard makes no warranty, expressed or implied, based on this literature and assumes no responsibility for consequential or incidental damages in the use of the systems described, including any warranty of merchantability or fitness. Information contained here is for evaluation only. We further reserve the right to modify and change products or literature at any time and without prior notice.

**STONHARD** A Division of **STONCOR** Group

[www.stoncor-europe.com](http://www.stoncor-europe.com)

Belgium	+32 67493710	Spain/Portugal	+351 707200088	Germany	+49 240541740
France	+33 160064419	United Kingdom	+44 1256336600	The Netherlands	+31 165585200
Poland	+48 422112768	East Europe	+31 165585200	Italy	+39 02253751